

Slimcard users manual



Introduction

Slimcard information backup machine is a novel convenient hi-tech product. It can easily backup telephone directory information of all kinds of SIM card to backup machine. It can also easily copy telephone directory information saved in backup machine to SIM card.

Features:

1. Backup and copy telephone directory of SIM card
2. Lose no information when mobile phone has been lost
3. Copy information of backup machine to any SIM card if user is using different SIM cards.
4. Lose no information when out of electricity
5. Function: needn't to connect to PC or PDA to operate

Model: **Slimcard**

Volume: 8KB (250 telephone directory records)

Users' Manual

1. Keys and instruction lamps

“-->Backup Machine” key ----- Input (backup) information of SIM card to backup machine

“Backup Machine --> key ----- Output (copy) information of backup machine to SIM card

Work lamp --- Normal light indicates correct input of SIM card; flash indicates low electricity power of battery; no light indicates no card or invalid card.

Input lamp --- Flash indicates processing (backup); no light when on any other condition.

Output lamp --- Flash indicates processing (copy); no light when on any other condition.

Finish lamp --- Normal light indicates complement of procedure in inputting or outputting; flash indicates wrong procedure; no light when on any other condition.

2. Operations

It just can backup after relief of PIN code protection on the mobile phone.

2.1 Inserting SIM card into Slimcard

Directed by the mark, insert SIM card, go forward after the Work lamp turns to be normal light; if the Work lamp can not be turned on, the system will not work, then please check whether SIM card has been correctly input, or whether it is a valid SIM card, or whether battery has been correctly installed, or whether there is no electricity power in battery; flash indicates lack of electricity power in battery.

2.2 Inputting information (backup)

Press “--> Backup Machine” key, the system will input (backup) information of SIM card to **Slimcard**.

The Input lamp will flash during the time. Finish lamp will be turned on after the procedure.

Finish lamp will flash if there is something wrong.

2.3 Outputting information (copy)

Press “Backup Machine -->” key, the system will output (copy) information of **Slimcard** to SIM card.

The Output lamp will flash during the time. Finish lamp will be turned on after the procedure.

Finish lamp will flash if there is something wrong.

2.4 Pulling out SIM card

Please pull out SIM card after finish in order to save electricity power in battery.

3. Check

If users wonder whether the information has been saved after the procedure, they can check it as following:

Delete one name saved in SIM card, and then output information of backup machine to SIM card.

Reshow of the name indicates successfully saved.

4. Warm Comments

- Please pull out battery in order to protect electric circuit when you needn't to use the backup machine for a long time.
- The backup machine can backup names and numbers saved in SIM card instead of those in mobile phone. Please firstly shift information in mobile phone to SIM card and then backup it to **Slimcard**.
- Backup machine can not copy information to SIM card when it hasn't have any information in it at all.
- Please don't pull out SIM card when it's working in order not to destroy or lose data.
- The backup machine can backup information of one SIM card instead of two SIM cards simultaneously.
- The backup machine can not backup messages saved in SIM card.

5. Warnings

- The backup machine can backup information of one SIM card. Backup machine will save information of an new SIM card and at the same time delete all the information before if you backup information of an new SIM card.
- SIM card will save new information copied from backup machine and at the same time delete all the information before if you copy information of backup machine to SIM card.

6. Problem solution

Problems	Check	Solutions
“ Work lamp ” has no response after inputting card	<ul style="list-style-type: none"> * Check battery * Check if SIM card has been correctly input 	<ul style="list-style-type: none"> * Reinstall/replace battery * Re-input SIM card
“ Finish lamp ” flash after pressing “--> Backup Machine” key	<ul style="list-style-type: none"> * Check if there is PIN code protection in SIM card * Check if SIM card is valid 	<ul style="list-style-type: none"> * Relief of PIN code protection on the mobile phone
“ Finish lamp ” flash after pressing “ Backup Machine --> ” key	<ul style="list-style-type: none"> * Check if there is PIN code protection in SIM card * Check if SIM card is valid * Check if backup machine has no information 	<ul style="list-style-type: none"> * Relief of PIN code protection on the mobile phone
“ Work lamp ” is normal but no response when pressing any key	<ul style="list-style-type: none"> * Check if SIM card is valid * Check if SIM card has been correctly input 	<ul style="list-style-type: none"> * Re-input SIM card

Slimcard product information on www.slimcard.info

Slimcard is een gedeponoerd handelmerk van MaxFax bv te Beekbergen (NL).